

New - Series 3 Carbon Head Crane - Rigging a 2:1 Halyard



1. Firstly take out the pin and sheave to enable access.

Using the suggested 4mm dyneema line. Form a figure of 8 knot and feed into the slot on the underside of the casting . We recommend leaving a tail



2. Loop over the line and feed back through the casting and down the mast via a mouse-line.



3. Re-fit the sheave and pin



4. Regular maintenance is a must-
Movement of the knot to avoid halyard chafe helps avoid breakage